


# **Deluge Manual Override Feature**





#### Manually opens deluge valve fully.

•Installed on the deluge valve bonnet.

Includes a red name plate with operational instructions.
Used on UL listed OCV deluge valves.

OCV's Ball Valve Deluge Manual Override Feature is used on deluge valves used in freshwater and saltwater deluge and pre-action fire suppression systems. In the event of a fire, any OCV deluge valve can be locally forced to FULL OPEN using this feature. When the ball valve is moved to the "OPEN" position, the bonnet chamber of the main valve will be vented to atmosphere, forcing the valve fully open, regardless of exterior pilot system function. Deluge valves equipped with the standard exterior trim option will come standard with a RED instruction plate to facilitate ease of use during a serious fire event.

#### MATERIALS

KIT NUMBER	MATERIALS	BALL VALVE PORT SIZE	DELUGE SIZES
# 970730	All Stainless Steel	3/8" NPT	1.25-6"
# 970731	All Stainless Steel	1/2" NPT	8-10"
* 970732	Monel/316 SS	3/8" NPT	1.25-6"
* 970733	Monel/316 SS	1/2" NPT	8-10"


#304 SS Plate and 316 SS Ball Valve is standard feature with Brass or SS trim. \*316 SS Plate and Monel Ball Valve can be supplied per special request.


## **COMPONENTS**

ITEM	DESCRIPTION	
1	Nameplate	
2	Ball Valve, 2-Port	
3	Mounting Screws	

### **SCHEMATIC**

Circled in red, the Deluge Manual Override Feature is shown on a Model 216-4FC Deluge Valve.





TOLL FREE 1.888.628.8258 • phone: (918)627.1942 • fax: (918)622.8916 • 7400 East 42nd Place, Tulsa, OK 74145 email: sales@controlvalves.com • website: www.controlvalves.com

**Global** performance. **Personal** touch.