

Model 8000VM shown The OCV Series 8000 float control valves are designed to maintain a desired level in a tank or reservoir by opening for filling the tank when fluid is below the high level point and closing tightly when the desired level is reached.


#### **SERIES FEATURES**

- The 8000 is a non-modulating valve; either full open or full closed. It is available in two basic configurations:
- Model 8000, with the float pilot provided separate from the main valve for remote mounting. This configuration is used when the fill line is located at the bottom of the tank.
  Model 8000VM, with the float pilot mounted on the main valve.
- Model 8000VM, with the float pilot mounted on the main valve. This configuration is typically used when the fill line is located at the top of the tank.
- All Series 8000 valves include an OCV Model 65 Basic Valve assembly and a Model 814 three-way rotary float pilot. For faster operation, valves 8" and larger also include a Model 3600 threeway auxiliary pilot.


## **BOTTOM FILL PILOT REMOTE MOUNTED**

# **VALVE FEATURES**

- > Operates automatically off line pressure.
- Heavy-duty, nylon-reinforced diaphragm.
- Rectangular-shaped, soft seat seal provides drip-tight Class VI closure.
- Diaphragm assembly guided top and bottom.
- Throttling seat retainer for flow and pressure stability.
- Easily maintained without removal from the line.
- ► Replaceable seat ring.
- Alignment pins assure proper reassembly after maintenance.
- ► Factory tested.
- Serial numbered and registered to facilitate replacement parts and factory support.



# **TOP FILL PILOT VALVE MOUNTED**




TOLL FREE 1.888.628.8258 • phone: (918)627.1942 • fax: (918)622.8916 • 7400 East 42nd Place, Tulsa, OK 74145 email: sales@controlvalves.com • website: www.controlvalves.com

**Global** performance. Personal touch.




## **VALVE OPERATION**



VALVES 8" - Larger

#### PILOT



email: sales@controlvalves.com • website: www.controlvalves.com



### FLOAT PILOT INSTALLATION

To protect the float ball from wave action within the tank, it is highly recommended that the float be installed in a stilling well. This is especially critical if the fill line exits into the top of the tank.

## **VALVE INSTALLATION**

For maximum efficiency, the OCV control valve should be mounted in a piping system so that the valve bonnet (cover) is in the top position. Other positions are acceptable but may not allow the valve to function to its fullest and safest potential. In particular, please consult the factory before installing 8" and larger valves, or any valves with a limit switch, in positions other than described.

#### Model 814 Float Pilot

The OCV Model 814 Float Pilot is a float-actuated, three-port, rotary disc pilot designed to provide on-off action to an OCV Model 65 main valve.

It features the following:

- (1) Integral mounting plate to facilitate installation within the tank.
- (2) Designed for mounting above the fluid level to prevent a cross-connection.
- (3) High and low level points are independently adjustable, allowing for optimum tank cycling.

The basic principle of operation of the 814 pilot is quite straightforward. There are three sets of ported passages in the pilot body, and matching sets in the lapped rotary disc.

- (A) With the float "down", the "S" port is blocked, and the "C" port is connected to "E" port. This allows the pilot to vent the diaphragm chamber of a main valve or auxiliary pilot, thus opening the main valve.
- (B) With the float "up", the "E" port is blocked, and "S" is connected to "C" port. This allows the pilot to pressurize the diaphragm chamber of the main valve or auxiliary pilot, thus closing the main valve.

#### **SIZING CONSIDERATIONS**

#### Sizing of Series 8000 Valves - Float Valves

While most Model 8000 valves are line sized, there are two factors that should be checked. Maximum flow rate should not exceed 25 ft/sec, in other words don't use a valve that is to small. At the same time, you don't want the valve so large that when it opens, it drops the system pressure so low that there is not enough pressure to close the valve when high level is reached. Our ValveMaster selection and sizing software covers this in detail. However, if you do not have access to the software on our web site, sizing within the flow limitations shown in the following table should result in satisfactory operation.

If the flow rate for a given valve will fall below the minimum shown, you might consider adding a pressure sustaining feature (Model 8000-3).

SIZE	1 1⁄4"	1 1/2"	2	<b>2</b> ½"	3"	<b>4</b> "	<mark>6</mark> "	8"	10"	12"	14"	16"	24"
Min. flow, gpm	14	23	50	75	115	200	450	780	1225	1750	2100	2750	6250
Max. flow, gpm	115	160	260	370	570	1000	2250	3900	6150	<b>8</b> 700	10,500	13,800	<b>J</b> 31,300

TOLL FREE 1.888.628.8258 • phone: (918)627.1942 • fax: (918)622.8916 • 7400 East 42nd Place, Tulsa, Oklahoma 74145 email: sales@controlvalves.com • website: www.controlvalves.com



### **VALVE SELECTION GUIDE**

By combining various control pilots, multiple valve functions can be performed on a single Series 8000 Float Control Valve. To find the combination function valve, select the desired features and then the model number. This chart shows only a sample of those most often specified valves. Consult the factory for specific data on the model you selected.

Combination valves can often reduce or eliminate other equipment. Example: If the system requires a Pressure Sustaining function, the sustaining feature can be added as a function of the Float Valve, Model 8000-3.

			002	. 0000		3000°C	oover oover	1 001	N' OON	N.2 001	Nº OOV	8000V	and a start and a start
Feature	80	80-	8	80-	8	80-	8	85-	80-	80	80-	80	Definition
Float Pilot Mounted On Valve							x	x	x	x	x		Pilot mounted on valve vs remote mount
Solenoid Override (Energize-to-Open		x			x			x			x		Solenoid, when deenergized, overrides float pilot to close valve
Solenoid Override (Energize-to- Close)			x			x			x			x	Solenoid, when energized, overrides float pilot to close valve
Pressure Sustaining				x	x	x				x	x	x	Maintains minimum valve inlet pressure

## **ABOUT YOUR VALVE**

OCV Control Valves was founded more than 60 years ago with a vision and commitment to quality and reliability. From modest beginnings, the company has grown to be a global leader just a half century later. In fact, OCV Valves can be found in some capacity in nearly every country around the lalaysia to aircraft fueling systems in Africa and from oil refineries in Bussia to water supply systems in

world from fire protection systems in Malaysia to aircraft fueling systems in Africa and from oil refineries in Russia to water supply systems in the USA and Canada. You will also find our valves in irrigation systems in Europe, South America and the Middle East.

The original foundation on which the company was built allows our team of professionals to not only provide the service required to be a worldwide supplier, but more importantly the opportunity to afford the personal touch necessary to be each of our customers' best partner. Simply stated, we take pride in all that we do.

Committed to the work they do, our employees average over 15 years of service. This wealth of knowledge allows us to provide quality engineering, expert support, exacting control and the know-how to create valves known for their long life.

Being ISO 9001 certified means we are committed to a quality assurance program. Our policy is to supply each customer with consistent quality products and ensure that the process is right every time. Our valves meet and exceed industry standards around the world. Including approvals by:



Check individual models for availability.

All valves are not created equal. OCV Control Valves proves that day in and day out. We stand behind our valves and are ready to serve your needs.

TOLL FREE 1.888.628.8258 • phone: (918)627.1942 • fax: (918)622.8916 • 7400 East 42nd Place, Tulsa, OK 74145 email: sales@controlvalves.com • website: www.controlvalves.com



### **SPECIFICATIONS**

NOTE: ALL waterworks valves meet the Low-Lead laws of the United States, including individual state laws, as of March 2014.



VALVE B	ODY & BONNET	DUCTIL	E IRON	CAST S	STEEL	STA	STAINLESS STEEL		
Material Sp	pecification		5/65-45-12 coated)	ASTM A2 (epoxy o	16/WCB coated)	ALL GRADES			
END CONNE	CTIONS								
Flange Standa	ard (also available in metric)	ANSI	B16.42	ANSI	B16.5	ANSI B16.5			
Flange Class		150#	300#	150#	300#	150#	300#		
Flange Face		Flat	Raised	Raised	Raised	Raised	Raised		
	rking Pressure	250 psi	640 psi	285 psi	740 psi	285 psi	740 psi		
S	crewed Working Pressure:	ANSI B1.20.	1 640 psi	Grooved E	nd Working Pres	SUICE: 300 psi			
INTERNALS									
Stem	STAINLE	SS STEEL							
Spring	STAINLE	SS STEEL							
Spool		DUCTILE	STAINLI	ESS STEEL					
Seat Disc Reta	iner	DUC STN ST	TILE IRON (epo) TL. (8" & SMALL	STAINLI	ESS STEEL				
Diaphragm Pl	ate		IRON (epoxy co	STAINLI	ESS STEEL				
Seat Ring (Trin			LOW-LEAD E	BRONZE OR STN.	. STL.	STN. STL.			
Upper Stem B			BRONZE OR T	TEFLON®	3	TEFI	ON®		
Lower Stem Bi	~	NOT APPLIC	ABLE FOR LOW-LI	EAD BROZE SEAT	RINGS / TEFLON I	For For STN. ST	L. SEAT RIN		
	PARTS (Rubber)				202				
	eat Disc/O-Rings		EI	PDM					
Operating Tem		i temperature alla	wance. 32°F	to 230°F					
COATINGS			NSF-61 EF	POXY COATING					
ELECTRICAL	SOLENOIDS								
Bodies			BRASS / OPTIO	NAL - STAINLE	SS STEEL				
Enclosures			WATER TIGH	HT, NEMA 1, 3, 4	, & 4X				
Power	AC, 60HZ - 24, 120, 240	, 480 VOLTS	AC, 50HZ - I	n 110 VOLT MU	LTIPLES DC,	6 12, 24, 240 V	OLTS		
Operation	ENERGIZE	TO OPEN (NO	ORMALLY CLOSE	D) DE-ENER	GIZE TO OPEN (N		1990)		
CONTROL P	ILOTS	<i>\$</i> 2			TEFL	ON® is a registered to	ademark of Du		
Bodies	LOW-LEAD BRONZE	STN	I. STL.	BONNET			- DIAPHRAGM PLATE		
Internal	STAINLESS STEEL	STAINL	ESS STEEL	SPRING			– ALIGHMENT PLUG		
		T		UPPER STEN GUIDE BUSHING			- DIAPHRAGM		
Tubing	COPPER	STAINL	ESS STEEL	SEAT DISC RETAINER		1	- SPOOL		
Fittings	LOW-LEAD BRASS	STAINL	ESS STEEL	STEN			- SEAT DISC - SEAT RING		
				LOWER STEN			- SEAT RING (TRIM)		
and the second	Globe Flanged Sizes			GUIDI			- BODY		
And in case of the local division of the loc	1.25" 1.5" 2" 2.5" 3	" 4" 6"	8" 10"	12" 14" 16'	18"* 20"*	24"			
Contraction of the second	32mm 40mm 50mm 65mm 80r		1.045	101201 (2020)	nm 450mm= 500mm= 60	)0mm			
					*CONSULT FAC	TORY			
-	Angle Flanged Sizes	im roumm roun	ini zoomini zoomini s	300mm 330mm 400m			400mm <sup>a</sup> 500mm <sup>a</sup> 600mm +CONSULT FACTORY		



Angle	e Flan	ged S	izes							
1.25"	1.5"	2"	2.5"	3"	4"	6"	8"	10"	12"	16"
32mm	40mm	50mm	65mm	80mm	100mm	150mm	200mm	250mm	300mm	400mm



.25"	1.5"	2"	2.5"	3"



**Globe/Angle Grooved Sizes** 1.5" 2.5" 3" 6"\* 2" 4" 32mm 50mm 65mm 80mm 100mm 150mm\* \*GLOBE ONLY

TOLL FREE 1.888.628.8258 • phone: (918)627.1942 • fax: (918)622.8916 • 7400 East 42nd Place, Tulsa, OK 74145 email: sales@controlvalves.com • website: www.controlvalves.com

Global performance. Personal touch.



#### DIMENSIONS

					U.S. 1	DIMENSION	IS - INCHE	S					
DIM	END CONN.	1 1/4-1 1/2	2	2 1/2	3	4	6	8	10	12	14	16	24
	SCREWED	8 3/4	9 7/8	10 1/2	13		7 <u>2</u> 22	6702	122	642	1220	223	420
A	GROOVED	8 3/4	9 7/8	10 1/2	13	15 1/4	20			್ಷ			553
	150# FLGD	8 1/2	9 3/8	10 1/2	12	15	17 3/4	25 3/8	29 3/4	34	39	40 3/8	62
	300# FLGD	8 3/4	9 7/8	11 1/8	12 3/4	15 5/8	18 5/8	26 3/8	31 1/8	35 1/2	40 1/2	42	63 3/4
	SCREWED	1 7/16	1 11/16	1 7/8	2 1/4								
В	GROOVED	1*	1 3/16	1 7/16	1 3/4	2 1/4	3 5/16						
	150# FLGD	2 5/16-2 1/2	3	3 1/2	3 3/4	4 1/2	5 1/2	6 3/4	8	9 1/2	10 5/8	11 3/4	16
	300# FLGD	2 5/8-3 1/16	3 1/4	3 3/4	4 1/8	5	6 1/4	7 1/2	8 3/4	10 1/4	11 1/2	12 3/4	18
	SCREWED	4 3/8	4 3/4	6	6 1/2				5. <del></del>		(**):		
С	GROOVED	4 3/8*	4 3/4	6	6 1/2	7 5/8	144						-
ANGLE	150# FLGD	4 1/4	4 3/4	6	6	7 1/2	10	12 11/16	14 7/8	17	4	20 13/16	
	300# FLGD	4 3/8	5	6 3/8	6 3/8	7 13/16	10 1/2	13 3/16	15 9/16	17 3/4		21 5/8	
	SCREWED	3 1/8	3 7/8	4	4 1/2		( <del>44</del>		5 <b>44</b>				-
D	GROOVED	3 1/8*	3 7/8	4	4 1/2	5 5/8			-				
ANGLE	150# FLGD	3	3 7/8	4	4	5 1/2	6	8	11 3/8	11		15 11/16	
	300# FLGD	3 1/8	4 1/8	4 3/8	4 3/8	5 13/16	6 1/2	8 1/2	12 1/16	11 3/4	(***)	16 1/2	-
E	ALL	6	6	7	6 1/2	8	10	11 7/8	15 3/8	17	18	19	27
F	ALL	3 7/8	3 7/8	3 7/8	3 7/8	3 7/8	3 7/8	6 3/8	6 3/8	6 3/8	6 3/8	6 3/8	8
G	ALL	6	6 3/4	7 11/16	8 3/4	11 3/4	14	21	24 1/2	28	31 1/4	34 1/2	52
Н	ALL	10	11	11	11	12	13	14	17	18	20	20	28 1/2

\*GROOVED END NOT AVAILABLE IN 1 1/4"


					METR	IC DIMENS	SIONS - M.I	M.					
DIM	END CONN.	DN32-DN40	DN50	DN65	DN80	DN100	DN150	DN200	DN250	DN300	DN350	DN400	DN600
]	SCREWED	222	251	267	330			0.00		(622 )	120	2231	
A	GROOVED	222	251	267	330	387	508	1.55	1.000		1.000		
i i	150# FLGD	216	238	267	305	381	451	645	756	864	991	1026	1575
	300# FLGD	222	251	283	324	397	473	670	791	902	1029	1067	1619
	SCREWED	37	43	48	57								
в	GROOVED	25*	30	37	44	57	84				()		
	150# FLGD	59-64	76	89	95	114	140	171	203	241	270	298	406
	300# FLGD	67-78	83	95	105	127	159	191	222	260	292	324	457
	SCREWED	111	121	152	165							· · · · ·	
С	GROOVED	111*	121	152	165	194	122	5 <b>22</b>	1000	1944		<u> </u>	
ANGLE	150# FLGD	108	121	152	152	191	254	322	378	432	4	529	
	300# FLGD	111	127	162	162	198	267	335	395	451		549	
	SCREWED	79	98	102	114								
D	GROOVED	79*	98	102	114	143				( <del></del>			
ANGLE	150# FLGD	76	98	102	102	140	152	203	289	279		398	
	300# FLGD	79	105	111	111	148	165	216	306	298	( <b></b> ).	419	
Е	ALL	152	152	178	165	203	254	302	391	432	457	483	686
F	ALL	98	98	98	98	98	98	162	162	162	162	162	203
G	ALL	152	171	195	222	298	356	533	622	711	794	876	1321
Н	ALL	254	279	279	279	305	330	356	432	457	508	508	724

For maximum efficiency, the OCV control valve should be mounted in a piping system so that the valve bonnet (cover) is in the top position. Other positions are acceptable but may not allow the valve to function to its fullest and safest potential. In particular, please consult the factory before installing 8" and larger valves, or any valves with a limit switch, in positions other than described. Space should be taken into consideration when mounting valves and their pilot systems.

A routine inspection & maintenance program should be established and conducted yearly by a qualified technician. Consult our factory @ **1-888-628-8258** for parts and service.

#### How to order your valve

When Ordering please provide: Series Number - Valve size - Globe or Angle -Pressure Class - Screwed, Flanged, Grooved -Trim Material - Adjustment Range - Pilot Options - Special needs / or installation requirements.



Represented by:

**TOLL FREE 1.888.628.8258** • phone: (918)627.1942 • fax: (918)622.8916 • 7400 East 42nd Place, Tulsa, 0k 74145 email: sales@controlvalves.com • website: www.controlvalves.com